



Low dark current and high speed ZnO metal–semiconductor–metal photodetector on SiO2/Si substrate

Deniz Çalışkan, Bayram Bütün, M. Cihan Çakır, Şadan Özcan, and Ekmel Özbay

Citation: Applied Physics Letters **105**, 161108 (2014); doi: 10.1063/1.4899297 View online: http://dx.doi.org/10.1063/1.4899297 View Table of Contents: http://scitation.aip.org/content/aip/journal/apl/105/16?ver=pdfcov Published by the AIP Publishing

Articles you may be interested in Metal–semiconductor–metal photodetector on as-deposited TiO2 thin films on sapphire substrate

J. Vac. Sci. Technol. B **31**, 020606 (2013); 10.1116/1.4794526

Effects of annealing temperature on the characteristics of Ga-doped ZnO film metal-semiconductor-metal ultraviolet photodetectors J. Appl. Phys. **113**, 084501 (2013); 10.1063/1.4791760

MgZnO-based metal-semiconductor-metal solar-blind photodetectors on ZnO substrates Appl. Phys. Lett. **98**, 221112 (2011); 10.1063/1.3596479

Electrical breakdown of ZnO nanowires in metal-semiconductor-metal structure Appl. Phys. Lett. **96**, 253112 (2010); 10.1063/1.3457169

Effect of high-energy electron beam irradiation on the properties of ZnO thin films prepared by magnetron sputtering

J. Appl. Phys. 105, 123509 (2009); 10.1063/1.3149783



This article is copyrighted as indicated in the article. Reuse of AIP content is subject to the terms at: http://scitation.aip.org/termsconditions. Downloaded to IP: 139.179.98.141 On: Fri, 24 Oct 2014 05:29:03



Low dark current and high speed ZnO metal–semiconductor–metal photodetector on SiO₂/Si substrate

Deniz Çalışkan, ^{1,2,a)} Bayram Bütün, ¹ M. Cihan Çakır, ¹ Şadan Özcan, ³ and Ekmel Özbay^{1,4} ¹Nanotechnology Research Center, Bilkent University, 06800 Bilkent, Ankara, Turkey ²Department of Nanotechnology and Nanomedicine, Hacettepe University, 06800 Beytepe, Ankara, Turkey ³Department of Physics Engineering, Hacettepe University, 06800 Beytepe, Ankara, Turkey ⁴Department of Electrical and Electronics Engineering and Department of Physics, Bilkent University, 06800 Bilkent, Ankara, Turkey

(Received 17 July 2014; accepted 11 October 2014; published online 21 October 2014)

ZnO thin films are deposited by radio-frequency magnetron sputtering on thermally grown SiO₂ on Si substrates. Pt/Au contacts are fabricated by standard photolithography and lift-off in order to form a metal-semiconductor-metal (MSM) photodetector. The dark current of the photodetector is measured as 1 pA at 100 V bias, corresponding to 100 pA/cm² current density. Spectral photoresponse measurement showed the usual spectral behavior and 0.35 A/W responsivity at a 100 V bias. The rise and fall times for the photocurrent are measured as 22 ps and 8 ns, respectively, which are the lowest values to date. Scanning electron microscope image shows high aspect ratio and dense grains indicating high surface area. Low dark current density and high speed response are attributed to high number of recombination centers due to film morphology, deducing from photoluminescence measurements. These results show that as deposited ZnO thin film MSM photodetectors can be used for the applications needed for low light level detection and fast operation. © 2014 AIP Publishing LLC. [http://dx.doi.org/10.1063/1.4899297]

Low dark current and high speed metal oxide ultraviolet (UV) photodetectors are of interest due to their potential use in civil applications such as air quality monitoring, gas detection, and flame detection and military applications such as UV communications and missile warning.¹ ZnO is an alternative material to the widely known GaN based material system that is used for these applications^{2,3} because of simpler growth technology and comparable device performance.⁴ Recently, ZnO based low dark current photodetectors have been fabricated by metal-organic chemical vapor deposition grown films,⁵ atomic layer deposition,⁶ ball milled nanoparticles,⁷ radio-frequency (RF) magnetron sputtering,⁸ and other various methods. Although dark currents for the devices are reported in the 10^{-9} – 10^{-12} A range, calculated dark current densities are in the order of nA/cm² or even higher. For high performance UV detection, much lower current densities are required.

Another important performance criterion for photodetectors is the time response of the device. Fast time response ZnO photodetectors were published recently, but all of these works report rise times in $\sim 10^{-9}$ s scales, although they are fabricated on good quality thin films.^{9–11} In this work, we present very low dark current density and very high speed UV photodetectors fabricated with reactively RF magnetron sputtered ZnO thin films on SiO₂/Si substrates.

Prior to the deposition of ZnO thin film, Si wafer was cleaned using the standard RCA recipe and then wet oxidized at 1100 °C to achieve 750 nm thick SiO₂ film on Si substrate. After dicing 10 mm × 10 mm pieces, the substrates were cleaned in acetone and isopropanol in ultrasonic bath, rinsed in running deionized (DI) water and dried by nitrogen.

After 5 min of dehydration on a hotplate at $120 \,^{\circ}$ C, the substrates were directly loaded to the Nanovak NVTS-400 combo PVD system. After achieving a 2.5×10^{-6} mbar vacuum level, O₂ and Ar gases were introduced to the system, both with partial pressures of 24/100, respectively. After sputter-cleaning the target for 10 min, 150 nm of ZnO thin film was deposited on the substrate at 1.85 mbar pressure, 80 W RF power, and a 0.5 Å/s deposition rate without intentional heating or cooling. No post annealing of films were applied. Scanning electron microscope (SEM) image of the grown film is shown in Fig. 1, indicating that the film was grown in island-growth mode as very dense and random, vertically aligned high aspect ratio grains, or nanowire-like structures. This type of growth leads to very high surfacearea/volume ratio through the film.

Contacts with 2 μ m width and 10 μ m spacing were photolithographically defined on the substrate. Pt is selected as Schottky contact on deposited ZnO, due to its high work function to obtain higher Schottky barrier and lower leakage




FIG. 1. SEM image of the grown ZnO thin film on SiO₂.

^{a)}Author to whom correspondence should be addressed. Electronic mail: dcaliskan@fen.bilkent.edu.tr




FIG. 2. XRD pattern obtained from the sample. (Inset) Gaussian fit and FWHM of the fit.

current. After deposition of Pt/Au (100 Å/1000 Å) using a Leybold Univex-350 e-beam evaporator, lift off was applied.¹² The total device active area was $100 \,\mu\text{m} \times 100 \,\mu\text{m}$.

X-ray diffraction (XRD) measurements were performed using a Rigaku powder diffractometer, and photoluminescence (PL) measurement was performed on a Horiba Jobin Yvon system. Current-voltage (IV) was performed with an Agilent B1500A semiconductor parameter analyzer, and the spectral photoresponse was measured using Spectral Products DK240 monochromator and Keithley SMU. Speed measurements were done by using a 266 nm Fianium fiber laser with a 10 ps pulse width and an Agilent 50 GHz oscilloscope.

XRD for structural analysis of the grown film is performed and result is shown in Fig. 2. The peak at 34.1° is (002) peak of ZnO. In the inset of Fig. 2, the Gaussian fit to (002) peak and full width at half maximum (FWHM) of the fit is shown. FWHM of the (002) peak is measured to be 1.1° and Scherrer equation gives approx. 7.4 nm of average crystallite size.

The PL measurement result is shown in Fig. 3. The band-gap excitation (BGE) peak is observed at 3.18 eV. O₂ or Zn vacancies are responsible for the short peak observed at 2.5 eV.⁴ Reactive deposition of the film results in a decrease at the intensity of this peak. The wide peak that is observed at 1.67 eV is associated with recombination centers




FIG. 4. Dark and photo IV of the fabricated MSM photodiodes. (Inset) Spectral responsivity.

Bias (V)

present in the ZnO crystal lattice, also originating through native defects.¹³ Surface band bending is a generally accepted the reason for the 1.54 eV peak in PL data.¹⁴ The nanowire like structure that is seen in the SEM image in Fig. 1 shows that the surface area of the grain boundaries is high. Due to this large surface area, it is expected that a surface band bending effect will be observed with the film that is validated with the 1.54 eV peak observed in the PL data.

Fig. 4 shows the dark current and photo current measurement results that were performed under illumination of a 330 nm wavelength and 984 nW optical power. Up to a 100 V bias, no breakdown is observed. As can be seen in the inset of Fig. 4, the spectral response measurement gives the peak responsivity of 0.35 A/W at 340 nm.

The rejection ratio between 340 nm and 450 nm was measured more than 300 for the device. Dark current measured from the device at a 100 V bias voltage was only 1 pA, which is limited with the measurement setup. This dark current corresponds to a 100 pA/cm^2 current density, which is the lowest value to date. Low photocurrent, with respect to the values in the literature, can be attributed to the lack of photoconductive gain due to high contact spacing and high number of recombination centers at the boundaries of the grains.

The time response measured from the device is shown in Fig. 5. Rise time (10%-90%) is measured as 22 ps. The




FIG. 3. PL graph for ZnO thin film.

FIG. 5. Rise time of the device. (Inset) Time response in nanosecond scale.

1100

This article is copyrighted as indicated in the article. Reuse of AIP content is subject to the terms at: http://scitation.aip.org/termsconditions. Downloaded to IP 139 179 98 141 On: Fri. 24 Oct 2014 05:29:03

fall time for the device was 8 ns, which fits to the exponential decay perfectly, showing that only one component exists in the time response. Rise times found in the literature for high speed ZnO based photodetectors are in nanoseconds.^{9,10,15–17} The surface band bending related peak observed in PL measurement and the vertically aligned grown ZnO nanorods, observed in SEM inspection, indicating high surface area, therefore high trap density, seem to be responsible for very fast recombination of photogenerated carriers, resulting low photoresponse but very fast time response.

In conclusion, Pt/Au contact metal-semiconductor-metal (MSM) photodetectors were fabricated on ZnO thin films grown on SiO₂/Si substrates by reactive RF magnetron sputtering. A very low dark current density of 100 pA/cm² at a 100 V bias voltage was achieved. 0.35 A/W responsivity at a 340 nm wavelength and rejection ratio of more than 300 between 340 nm and 450 nm was measured from the device. The very fast response of 22 ps of the rise time and 8 ns of the fall time were measured from the device. Low dark current density and high speed response at a cost of responsivity can be attributed to high number of recombination centers due to high surface area due to high aspect ratio and dense grains. These results show that low dark current densities and a fast time response can be achieved from a simple processing of the deposited ZnO films with a carefully adjusted deposition process.

This work was supported by the projects DPT-HAMIT, DPT-FOTON, NATO-SET-193, and TUBITAK under Project Nos. 113E331, 109A015, and 109E301, respectively.

One of the authors (E.O.) also acknowledges partial support from the Turkish Academy of Sciences. We would like to thank Dr. Abdullah Ceylan for the XRD measurements and Pakize Oztop for the PL measurements.

- ¹M. Razeghi and A. Rogalski, J. Appl. Phys. **79**, 7433 (1996).
- ²M. Gökkavas, S. Butun, T. Tut, N. Biyikli, and E. Ozbay, Photonics Nanostruct. Fundam. Appl. 5, 53 (2007).
- ³S. Butun, M. Gökkavas, H. Yu, and E. Ozbay, Appl. Phys. Lett. **89**, 073503 (2006).
- ⁴Ü. Özgür, Ya. I. Alivov, C. Liu, A. Teke, and M. A. Reshchikov, J. Appl. Phys. **98**, 041301 (2005).
- ⁵Y. Liu, C. R. Gorla, S. Liang, N. Emanetoglu, Y. Lu, H. Shen, and M. Wraback, J. Electron. Mater. **29**, 69 (2000).
- ⁶P. Hazra, S. K. Singh, and S. Jit, J. Semicond. Technol. Sci. 14, 117 (2014).
- ⁷S. P. Chang and K. J. Chen, J. Nanomater. **2012**, 602398.
- ⁸M. Liu and H. K. Kim, Appl. Phys. Lett. **84**, 173 (2004).
- ⁹K. W. Liu, J. G. Ma, J. Y. Zhang, Y. M. Lu, D. Y. Jiang, B. H. Li, D. X. Zhao, Z. Z. Zhang, B. Yao, and D. Z. Shen, Solid State Electron. **51**, 757 (2007).
- ¹⁰J. Sun, F. J. Liu, H. Q. Huang, J. W. Zhao, Z. F. Hu, X. Q. Zhang, and Y. S. Wang, Appl. Surf. Sci. 257, 921 (2010).
- ¹¹Z. Bi, X. Yang, J. Zhang, X. Bian, D. Wang, X. Zhang, and X. Hou, J. Electron. Mater. 38, 609 (2009).
- ¹²D. Caliskan, B. Butun, S. Ozcan, and E. Ozbay, J. Vac. Sci. Technol. B 31, 020606 (2013).
- ¹³T. Minami, H. Nanto, and S. Takata, J. Lumin. 24/25, 63 (1981).
- ¹⁴J. C. Moore and C. V. Thompson, Sensors **13**, 9921 (2013).
- ¹⁵S. Liang, H. Sheng, Y. Liu, Z. Huo, Y. Lu, and H. Shen, J. Cryst. Growth **225**, 110 (2001).
- ¹⁶D. Jiang, J. Zhang, Y. Lu, K. Liu, D. Zhao, Z. Zhang, D. Shen, and X. Fan, Solid State Electron. 52, 679 (2008).
- ¹⁷Q. A. Xu, J. W. Zhang, K. R. Ju, X. D. Yang, and X. Hou, J. Cryst. Growth 289, 44 (2006).